

SMART PRO

Adjustable stroke: 2.4 2.7 3.0 3.3 3.6 3.9 4.2mm
Removeable 1500mAh battery pack ,Lasting 5hours at 8V 4.2mm stroke
OLED display 4-12V full adjustable by 0.1V
Jumpstart volt 9V



SMART PRO

**WIRELESS TATTOO PEN
ADJUSTABLE STROKE
USER MANUAL**




Product Diagram



RCA Adaptor

Power on/off
Start/Pause
Jumpstart on/off



Click +/- increase/decrease volt by 0.1V
Long press +/- quickly increase/decrease volts by 0.1V




Short circuit protection



Over current protection




Charging failure

 Capacity

 Charging

 Start/Pause icon

 Jumpstart on/off icon

Product Specification

| | |
|-----------------------------|--|
| Material | Aircraft Aluminum |
| Motor Corless motor | 8V 6500RPM |
| Adjustable Stroke | 2.4 2.7 3.0 3.3 3.6 3.9 4.2mm |
| Operate Volt | 4-12V |
| JumpStart Volt | 0.3s 9V |
| Battery Type | Polymer Lithium Battery |
| Battery Capacity | 1500mAh |
| Battery Charge | 2 hours with 2A 5V Adaptor Type-c cord |
| Accessories Included | 1pc Smart pro pen, 1pc RCA adaptor, 1pc RCA cord, 1pc Typec charging cord, 1set tool bag |

SAFETY PROTECTION

- Output short circuit and overcurrent protection.
- Input dual protection, the batteries come with overcharge and overdischarge protection, Electric board set up short circuit, overcurrent, overcharge protection.

Operate

- Long Press Power Button to POWER ON without JumpStart feature.

- Quickly Double press Power Button to POWER ON with JumpStart feature , and the lightning Icon on Display will appear as well.
- The unit will start with previously adjusted Voltage.
- Press Power Button for Start / Pause the machine. Pedal icon will indicate the machine working.
- The unit comes with power saving mode. When any switch is not pressed for 10 seconds then screen brightness will automatically decrease 50%. It will save battery capacity significantly. Normal Brightness will be back automatically when any switch will be press again.
- When you connect charging cable to charge the battery pack, capacity bar will appear.
- Long press the power button to POWER OFF ,The unit will automatically switch off if any no activity recorded for 5minutes.

Error

- E1: The display shows E1 which means short circuit protection, It will be restored to standby state after 5 seconds.
- E2: The display shows E2 means over current protection.
- E3: The display screen shows E3 means charging failure, please replace the charging wire or charger.

Warranty

The unit warranty repair for a period of 1 years from the original date of purchasing. If you discover a defect in a product covered by this warranty, we will repair the item for free . Proof of purchase in the form of a sales receipt must be provided for warranty repair.

Exclusions: The warranty does not coverage extend to damage caused by misuse , abuse , unauthorized modification, improper storage conditions, lightning, or natural disasters. The warranty does not cover parts that are subject to normal wear and tear, such as power cords. Limits of Liability: Should the product fail , your sole recourse shall be repair or replacement , as described in the preceding paragraphs. We will not be held liable to you or any other party for any damages that result from the failure of this product. Damages excluded include, but are not limited to, the following: lost profits , lost savings ,lost data, damage to other equipment, and incidental or consequential damages arising from the use , or misuse of this product . By installing or using the product, the user accepts all terms described herein.

Kindly Suggest store the unit in a dry place without direct sunlight. If it is not used for a long time, it is recommended to charge and discharge the product once every 3 months to prolong the service life of the battery.